IMPORTANT! RETAIN THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE!

INSTRUCTION MANUAL FOR RIDE ON CAR MERCEDES BENZ G350D



This toy is produced in conformity with the requirements of Toy Safety Directive 2009/48/EC of the European Parliament and the council, National regulations and the applicable European standards.

TO GUARANTEE THE SAFE USE OF THIS PRODUCT FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL:

IMPORTANT! WARNINGS!

- ❖ CAUTION! NEVER LEAVE THE CHILD UNATTENDED!
- CAUTION! THIS TOY HAS NO BRAKE!
- CAUTION! THIS TOY IS NOT SUITABLE FOR CHILDREN UNDER 12 MONTHS AND WEIGHT MORE THAN 25kg. DO NOT OVERLOAD!
- ❖ CAUTION! NOT TO BE USED FOR CHILDREN MORE THAN 36 MONTHS!
- ❖ CAUTION! THIS PRODUCT IS NOT A TRANSPORT MEANS!
- ❖ CAUTION! DO NOT USE ON ROAD LANES!
- **❖ CAUTION!** KEEP AWAY FROM FIRE!
- CAUTION! BEFORE USE, CHECK THE GOOD WORKING ORDER AND FIXING OF ALL PARTS. Do not use the product if you find any missing or damaged parts!
- CAUTION! TO AVOID DANGER OF INJURY, REMOVE PARENT PUSHBAR AND FOOT REST, ONCE YOUR CHILD START TO RIDE THE TOY BY ITSELF.
- CAUTION! WHEN YOU DIRECT THE RIDE ON CAR BY THE PARENT PUSHBAR, ALWAYS USE THE FOOT REST TO AVOID INJURY THE CHILD'S FEET!
- Use for children from 12 to 36 months!
- Not to be used by two children simultaneously!
- Adult assembly only!
- The child must wear shoes at all times when using the toy! It is advisable to use helmet and protectors.
- No running or skating when pushing the ride on car with child in it.
- Use only during the day and in places with good lighting.
- Do not let children touch the wheels or stand close to them while the ride on car is moving!
- If there are stickers going off, you must stick them back or remove them to avoid children swallowing them
- Do not use spare parts or other components, which are not supplied by the producer! The producer revokes all responsibility in case parts different from the original ones have been used.
- Do not make changes or modifications to the construction! If necessary, contact the retailer or an authorized service center for advice and repair.
- Use the product only for its purpose!
- Do not allow presence of children under 3 years before assembly of the product is complete, to avoid access to small or loose parts!
- Do not tie strings or accessories to the product in order to avoid the risk of suffocation.
- Use only on even playgrounds and at a safe distance from streets or road lanes for vehicles!
- Do not use the product near stairs, escalators, protrusions, swimming pools etc.!
- Keep nylon packages away from children to avoid risk of suffocation!

IMPORTANT! WARNINGS AND GUIDELINES FOR BATTERY USE

- Do not allow children to access or play with the batteries!
- Use only batteries of the designated type and power.
- Do not use batteries of different types.
- Do not mix new with used batteries.
- Follow the designated polarity in the battery compartment.
- Remove damaged or worn out batteries.
- Remove the batteries when the product will not be used for long time.
- Do not throw the batteries in open fire. Do not take the batteries to pieces.

CAUTION! Waste from depleted or unusable batteries must be disposed of separately. It is forbidden to throw them out in containers for household waste. Dispose of the batteries only at the specified places.



MAIN FEATURES OF THE PRODUCT

- The toy is intended for a child aged from 12 months to 36 months and weighing up to 25 kg!
- When the child is sitting in it, the ride on car can be propelled by the child's feet or by the adult pushing the ride on car by the parent push bar
- Safety bumper
- Foot rest
- Steering wheel with horn and melodies
- Parent push bar
- Batteries 2 pcs type AA/1,5V (not included in the set)

MAIN PARTS

1. Car body x 1 pc		2. Steering wheel x1 pc	3. Backrest x1 pc	
4. Safety bumper x2 pc	0	5. Spare tire x 1pc	6. Thumb latch x1 pc	~
7. Parent pushbar x 1 pc	9	8. Connecting tube x 1 pc	9. Canopy x 1 pc.	
10. Canopy stick x 1 pc		11. Cup holder x 1 pc	12. J-shaped stick x 1 pc	7
13. M5x28 screw x 4 pcs	1	14. M5 nut x 4 pcs	15. Screw x 3 pcs	and

Please make sure all the parts are available.

ASSEMBLY UNSTRUCTIONS AND FUNCTIONS

WARNING! FOLLOW EXACTLY THE INSTRUCTIONS AND SEQUENCES FOR ASSEMBLY AND USING THE PRODUCT FROM THE BELOW FIGURES.

WARNING! CHECK THE SECURITY OF FIXING AFTER PERFORMING ANY OPERATION!

Required tools for performing some operations: screwdriver (not included).

The toy assembly operations and functions are numbered from 1 to 10.

Use the descriptions below along with the illustration bearing the same number.

ASSEMBLY

1. ASSEMBLY OF J-SHAPED STICK

Insert the j-shaped stick into the front of the car body, as shown in the figure.

2. ASSEMBLY OF THE STEERING WHEEL

Remove the screw and nut from the steering wheel. Insert the end of the j-shaped stick in the fixing element of the safety bumper and in the steering wheel. Fix the steering wheel with screw and nut

3. ASSEMBY OF SPARE TIRE

Place the spare tire on the backside of the car body. Fix with two screws, using screwdriver.

4. ASSEMBLY OF THE BACKREST

Insert the backrest in the respective place of the car body.

5. ASSEMBLY OF THE PARENT PUSH BAR TO THE CONNECTING TUBE

Connect the parent push bar and connecting tube and fix them with two screws and nuts.

Unscrew the screw and nut at the end of the connecting pipe so that it is ready for mounting to the body.

6. ASSEMBLY OF THE PARENT PUSH BAR

Insert the parent push bar into the hole in the backrest, turn the car body upside down and secure with the screw and nut from the connecting pipe.

7. ASSEMBLY OF THE SAFETY BUMPER

Mount each of the arms of the safety bumper to the backrest through the thumb latch. Then insert the both free ends of the safety bumper to the fixing element.

8. ASSEMBLY OF THE CANOPY TO THE CANOPY STICK

Mount the canopy to the canopy stick with screw and nut.

9. ASSEMBLY OF THE CANOPY TO THE BACKREST

Insert the canopy to the hole of the backrest. Make sure the canopy is well fixed and secured.

10. FUNCTIONS

To use the functions of the toy:


- Unscrew the cover, using screwdriver and remove the cover.
- Place 2 pcs batteries type AA /1,5V, keeping the indicated polarity.
- Press the button to check if the functions are activated.
- · Place back the cover and screw it.




















FUNCTIONS



button for melodies

1 - STEERING WHEELS WITH MELODIES AND SOUNDS

Press the button both side of the steering wheels for melodies and horn sound.

1 - PARENT PUSH BAR AND FOOT REST

- When the ride on car is propelled by the child, retract the footrest inwards as shown in the figure.
- When the ride on car is operated by an adult via the parental push handle, pull the footrest out.



CARE AND MAINTENANCE INSTRUCTIONS

- * Regularly check the plastic parts of the ride on car for any cracks or damage.
- Regularly oil the moving parts.
- Clean the toy by using a damp soft towel or sponge and a mild soap. Do not pour water on the toy.
- Do not clean with aggressive detergents containing abrasive particles, ammonia, bleach or spirit.
- Store the product in a clean and dry place, without moisture and at a safe distance from heat sources! Do not subject to direct environmental effect – sun, rain, moisture or harsh temperature changes!
- Do not use the product on muddy, sandy or gravel covered terrains, which can damage the moving parts.
- In case of problems related to the normal use, turn for advice or repair to the authorized service points.

Materials used: plastic, metal

"Mercedes-Benz", , and the design of the enclosed product are subject to intellectual property protection owned by Daimler AG. They are used by Ningbo Prince Toys Co.,Ltd. under license.

ROCMB0210xxx /653-P

Producer: Produced for Chipolino in PRC Importer: CHIPOLINO LTD., 1 Goliamokonarsko Shosse Str, Plovdiv, BULGARIA; tel.: +359 32 600 889;