

ATTENTION! KEEP THIS MANUAL FOR FUTURE REFERENCE!

**INSTRUCTION MANUAL FOR USE
OF BABY TWIN STROLLER
“MAXI MIX”**

**MAXI
MIX**



This stroller **chipolino** has been manufactured in accordance with the Product Safety Directive 2001/95/EU of the European Parliament and The Council and with European standard EN 1888-1 “Child care articles. Wheeled child conveyances. Part 1: Baby strollers and carry cot” and the regulations of national law, including Consumer Protection Law.

**FOLLOW ALL WARNINGS, INSTRUCTIONS AND RECCOMENDATIONS IN
THIS MANUAL IN ORDER TO GUARANTEE THE SAFE USE OF THIS PRODUCT!**

CAUTION! WARNINGS!


- ❖ **NEVER LEAVE YOUR CHILDREN UNATTENDED!**
- ❖ **FOR NEWBORN BABIES THE MOST LYING POSITION OF THE BACKRESTS IS RECOMMENDED!**
- ❖ **THE SITTING POSITION OF THE RECLINING SEATS IS TO BE USED ONLY FOR A CHILDREN AT LEAST 6 MONTHS OLD!**
- ❖ **KEEP AWAY FROM FIRE!**
- ❖ **DO NOT LIFT THE STROLLER BY ITS FRONT BUMPER!**
- ❖ **ALWAYS USE THE SAFETY BELTS ONCE THE CHILDREN CAN SIT UNAIDED!**
- ❖ **MAKE SURE ALL PARKING DEVICES ARE ENGAGED BEFORE USE.**
- ❖ **IN ORDER TO AVOID INJURY, MAKE SURE CHILDREN ARE AT SAFE DISTANCE FROM THE STROLLER DURING ITS ADJUSTING, UNFOLDING OR FOLDING!**
- ❖ **DO NOT ALLOW YOUR CHILDREN TO PLAY WITH THE STROLLER!**
- ❖ **THIS PRODUCT IS NOT SUITABLE FOR RUNNIG OR SKATING!**
- ❖ Use the stroller for children weighing not more than 15 kgs per child.
- ❖ Adult assembly is required!
- ❖ Do not put additional mattresses thicker than 15 mm in the seats!
- ❖ Always activate the parking device when you put the children in or out of the stroller!
- ❖ Make sure the safety belts are correctly fastened and adjusted before each use.
- ❖ The maximum load for the storage basket is 3 kg per basket!
- ❖ The maximum load of the diaper bag is up to 2 kg!
- ❖ Do not overload the stroller! Every load attached to the handle, bumper, and backrest or on the side of the stroller will affect its stability!
- ❖ This stroller is suitable for two children.
- ❖ Only use spare parts or other components, which are recommended or supplied by the producer! In the contrary case the producer is not responsible for the product's safety.
- ❖ Do not make any changes or modifications to the stroller's construction! In case of problems contact the dealer or an authorized repair service for advice and/or repair.
- ❖ Do not use this stroller if you find missing or damaged parts!
- ❖ Do not allow children younger than 3 years near the stroller during its assembly!
- ❖ Do not attach any strings or long cords to the stroller in order to avoid risk of suffocation!
- ❖ Do not use the stroller on stairs or escalators and pay attention when overcoming a curb or a step.
- ❖ Keep the plastic packaging away from children in order to avoid risk of suffocation!



MAIN FEATURES

- ❖ This stroller is suitable for two newborn babies or children aged up to 36 months or weighing up to 15 kgs per child;
- ❖ 5-point safety harnesses;
- ❖ Adjustable backrests;
- ❖ Adjustable canopies;
- ❖ Two Foot covers – included;
- ❖ Mama bag for accessories – included;
- ❖ Straight and swivel motion of the front wheels.

MAIN PARTS DIAGRAM



ASSEMBLY INSTRUCTIONS AND FUNCTIONS

This stroller is supplied partially assembled. In order to complete the assembly, you don't need any tools.

IMPORTANT! Follow exactly the instructions given and check the pictures. Keep your hands from entrapment!

IMPORTANT! After each operation, make sure that you have followed the instructions correctly and the fixing is stable!

IMPORTANT! In most cases after the completion of an operation you will hear a clicking sound.

The assembly, disassembly and functions are numbered from 1 to 11. Use the operations descriptions given in this manual and their matching picture.

1 – UNFOLDING THE STROLLER

2 – FRONT WHEELS

2-1 Installation of front wheels

2-2 Straight and swivel motion of front wheels

Note: When you move the stroller on uneven surfaces, it is recommended to fix the wheels in straight motion.

3 – ASSEMBLY OF REAR WHEELS

3-1 Installation of rear axis

3-2 Assembly of wheels to the rear axis – press the button and insert the wheel into the axis. Release to fix.

3-3 Parking device

IMPORTANT! Always apply the parking devices while stroller is not in motion to avoid sudden sliding and injuries!

4 – ASSEMBLY OF FOOT RESTS

Place the footrests to the frame and push to fix them at place.

5 – SAFETY BUMPERS

6 – CANOPIES

CAUTION! Always attach the canopies at the back of the seats in order to prevent the children from sliding off and injury.

7 – HEIGHT ADJUSTMENT OF HANDLE

Press the buttons at both sides of handle and set the handle bar upwards or downwards up to the required position.

8 – ADJUSTING THE BACKRESTS RECLINE POSITIONS

Press mechanisms (1) and set them upwards and downwards (2) until you reach the required position.

9 – RESTRAINT SYSTEM (SAFETY BELT)

9-1 Unlock: Press the button at central button and split the belts;

9-2 Locking the belts

Adjust the belts length by the sliders/adjusters.

CAUTION! Belts must be snug to children's bodies and must not be twisted.

IMPORTANT! Periodically check to ensure that the seat belt is securely attached to the stroller frame as well as securely fastened. The seat belt straps must not be damaged, worn out or twisted and they must provide stable connection!

CAUTION! Babies aged under 6 months must be put in the stroller only when seats' backrests are in most lying position! Before you place the babies in the seats, remove the shoulder safety belts or toss them to the seats' sides and cover the seats with soft pad that is no thicker than 15 mm!

10 – LEG REST ADJUSTMENT

Press the buttons on both sides of leg rest and move it down;

Push each leg rest up with your hand to reach higher position;

By each fixing you must hear click sound.








11 – FOLDING THE STROLLER







IMPORTANT! Before folding the stroller the parking device must be engaged, unfasten the fabric from front bumper and the storage basket should be empty.

11-1 – Pull the fabric cover of canopy from the side tubes of handle;

11-2 – Pull upwards the side folding mechanisms at both sides;

11-3 – Fold the stroller and fix it with the hook.






CARE AND MAINTENANCE GUIDELINES

- ❖ The brakes and wheels wear out faster than other parts. Replace them when necessary.
- ❖ Regularly oil the moving parts. Use silicone oil or silicone spray for oiling.
- ❖ Clean and oil all dirty metal and plastic parts regularly.
- ❖ Clean the fabrics, plastic parts and metal parts with damp cotton cloth or sponge and mild soap.
- ❖ Do not use aggressive detergents, solvents, bleach or spirits to clean your stroller.
- ❖ Always leave the stroller to fully dry after cleaning before you use it or store it. Mold could form if you keep your stroller moist.
- ❖ Always store your stroller indoors in clean and dry place. Do not expose to direct environment influence - sun, rain, moisture and high temperature intervals.
- ❖ Please, contact your authorized dealer for problems connected with the use or repair of this stroller.

Fabric Composition:

Outer: 100% Polyester

Filling: 100% Polyester



KBMM021xxxx



Bulgaria, Plovdiv, str. Golyamokonarsko shosse 1

www.chipolino.com