

**IMPORTANT! RETAIN THIS INSTRUCTION MANUAL
FOR FUTURE REFERENCE!**

**INSTRUCTION MANUAL FOR
RIDE ON CAR
Mercedes-AMG GLE 63**



This toy is produced in conformity with the requirements of Toy Safety Directive 2009/48/EC of the European Parliament and the Council, the regulation on essential requirements and conformity assessment of toys, the regulation on conformity marking and the applicable European standards.

TO GUARANTEE THE SAFE USE OF THIS PRODUCT FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL:

IMPORTANT! WARNINGS!

- **CAUTION!** NEVER LEAVE THE CHILD UNATTENDED!
- **CAUTION!** THIS TOY HAS NO BRAKE!
- **CAUTION!** THIS TOY IS NOT SUITABLE FOR CHILDREN UNDER 2 YEARS AND WEIGHT MORE THAN 23kg. DO NOT OVERLOAD!
- **CAUTION!** THIS PRODUCT IS NOT A TRANSPORT MEANS!
- **CAUTION!** DO NOT USE ON ROAD LANES!
- **CAUTION!** KEEP AWAY FROM FIRE!
- **CAUTION!** BEFORE USE, CHECK THE GOOD WORKING ORDER AND FIXING OF ALL PARTS. Do not use the product if you find there are missing or damaged parts!
- **CAUTION!** TO AVOID THE DANGER OF INJURY, REMOVE PARENT PUSHBAR AND FOOT REST, ONCE YOUR CHILD CONTROLS THE TOY BY ITSELF.
- **CAUTION!** WHEN YOU DIRECT THE RIDE ON CAR BY THE PARENT PUSHBAR ALWAYS USE THE FOOT REST TO AVOID HURTING THE CHILD'S FEET!
- Use for children above 2 years!
- Do not use for two children at the same time!
- Adult assembly only!
- The child must wear shoes when using the toy! It is advisable to use helmet and protectors.
- No running or skating when pushing the ride on car with child in it.
- Use only during the day and in places with good lighting.
- Do not let children touch the wheels or stand close to them while the ride on car is moving!
- If there are stickers going off, you must stick them back or remove them to avoid children swallowing them.
- Do not use the product if you find missing or damaged parts!
- Do not use spare parts or other components, which are not supplied by the producer! The producer revokes all responsibility in case parts different from the original ones have been used.
- Do not make changes or modifications to the structure! If necessary, contact the retailer or an authorized service center for advice and repair.
- Use the product only for its purpose!
- Do not allow presence of children under 3 years before assembly of the product is complete, to avoid access to small or loose parts!
- Do not tie strings or accessories to the product in order to avoid the risk of suffocation.
- Use only on even playgrounds and at a safe distance from streets or road lanes for vehicles!
- Do not use the product near stairs, escalators, protrusions, swimming pools etc.!
- Keep nylon packages away from children to avoid risk of suffocation!


IMPORTANT! WARNINGS AND GUIDELINES FOR BATTERY USE

- After inserting batteries, always secure the battery compartment with the cover.
- Do not allow children to access or play with the batteries!
- Use only batteries of the designated type and power.
- Do not use batteries of different types.
- Do not mix new with used batteries.
- Follow the designated polarity in the battery compartment.
- Remove damaged or worn out batteries.
- Remove the batteries when the product will not be used for long time.
- Do not throw the batteries in open fire. Do not take the batteries to pieces.
- **CAUTION!** Waste from depleted or unusable batteries must be disposed of separately. It is forbidden to throw them out in containers for household waste. Dispose of the batteries only at the specified places.














MAIN FEATURES


- The toy is intended for a child above 2 years with weight not more than 23kg!
- When the child is sitting in it, the ride on car can be propelled by the child's feet or by the adult pushing the ride on car by the parent pushbar.
- Parent pushbar is height adjustable
- Safety bumper
- Foot rest
- Steering wheel with horn and melodies
- Batteries 2 pcs type AA/1,5V (not included in the set)
- Dimensions 69 x 48.8 x 93 cm.



MAIN PARTS

Please make sure all the parts are available

		
1. CAR BODY		2. STEERING WHEEL
		
3. BACK REST	4. DRIVING AXLE	5. FRONT DRIVING WHEELS
 RIGHT LEFT		
6. SAFETY BUMPER		7. PARENT PUSHBAR
		
8. SCREW for front wheels, 4 pcs, Ø3.5		
		
9. SCREW for front wheels, 1 piece, Ø4		
		
10. SCREW for steering wheel, 1 piece, M5		
		
11. NUT handlebar, 1 piece, M5		

12. CANOPY 	13. CANOPY FRAME 
14. COVER FOR FIXING THE CANOPY 	15. SCREW for the cover for fixing the canopy, 6 pcs, Ø3.5 

ASSEMBLY GUIDELINES

CAUTION! FOLLOW EXACTLY THE GUIDELINES AND THE SEQUENCE OF ASSEMBLY AND USE OF THE PRODUCT WHICH YOU WILL FIND IN THE FIGURES IN THE MANUAL.

CAUTION! AFTER EACH STEP, CHECK THAT FIXING IS STABLE!

Tools needed for some assembly steps: screwdriver (not included in the set).

Assembly steps and functions are numbered from 1 to 14. Use their descriptions below along with the figure of the same number.

ASSEMBLY

1 - DRIVING AXLE ASSEMBLY

Turn the car body around and insert the straight end of the driving axle through the opening for the steering wheel until it shows.

2 - FRONT DRIVING WHEELS ASSEMBLY

3 - INSERTING BATTERIES IN THE STEERING WHEEL. STEERING WHEEL ASSEMBLY.

4 - BACKREST ASSEMBLY

IMPORTANT: Before assembling the backrest, set the knob into position “running direction”.

5 - ATTACHING AND DETACHING THE SAFETY BUMPER

6 - ATTACHING AND DETACHING THE PARENT PUSHBAR.

7 - ATTACHING AND DETACHING OF THE CANOPY






7-1 - Attaching the canopy frame









7-2 - Attaching the cover for fixing the canopy







7-3 - Attaching the canopy to the car body



FUNCTIONS

- 8 - STEERING WHEEL
- 9 - LUGGAGE DEPARTMENT UNDER THE SEAT
- 10 - FOOT REST
- 11 - ADJUSTING THE HEIGHT OF THE PARENT PUSHBAR
- 12 - ADJUSTING THE CANOPY
- 13 - DETACHING THE CANOPY
- 14 - TOY REGIMES: "RUNNING MODE" AND "PARENT PUSHBAR"











CARE AND MAINTENANCE INSTRUCTIONS

- Regularly check the plastic parts of the ride on car for any cracks or damage.
- Regularly oil the moving parts.
- Clean the toy by using a damp soft towel or sponge and a mild soap.
- Do not clean with aggressive detergents containing abrasive particles, ammonia, bleach or spirit.
- Store the product in a clean and dry place, without moisture and at a safe distance from heat sources! Do not subject to direct environmental effect – sun, rain, moisture or harsh temperature changes!
- Do not use the product on muddy, sandy or gravel covered terrains, which can damage the moving parts.
- In case of problems related to the normal use, turn for advice or repair to the authorized service points.

Materials used: plastic, metal.

"Mercedes-Benz", ,  and the design of the enclosed product are subject to intellectual property protection owned by Daimler AG. They are used by Dongguan Chi Lok Bo Company Limited under license.

Producer: Produced for Chipolino in PRC
Importer: CHIPOLINO LTD., 1 Goliamokonarsko Shosse Str,
Plovdiv, BULGARIA; tel.: +359 32 600 889;
www.chipolino.com